


ALABAMA CONTRACTORS LICENSE PRACTICE EXAM (SAMPLE)

STUDY GUIDE



Prepare with structure. Pass with confidence



Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright	1
Table of Contents	2
Introduction	3
How to Use This Guide	4
Questions	5
Answers	8
Explanations	10
Next Steps	16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

Questions

SAMPLE

1. What is the minimum slope percentage for ground directly adjacent to the foundation?
 - A. 2%
 - B. 5%
 - C. 3%
 - D. 10%
2. What is the maximum depth a stud in an exterior wall can be notched?
 - A. 15 percent of width
 - B. 20 percent of width
 - C. 25 percent of width
 - D. 30 percent of width
3. What is the maximum horizontal spacing interval for PVC hydronic piping?
 - A. 2.67 feet
 - B. 3 feet
 - C. 4 feet
 - D. 6 feet
4. How many screws are required to connect steel roof trusses to a load-bearing wall?
 - A. 6
 - B. 8
 - C. 10
 - D. 12
5. Live loads or floors and roofs must be posted by the owner when they exceed ____ PSF.
 - A. 25
 - B. 30
 - C. 50
 - D. 100

- 6. How long must an employer keep employee records according to federal guidelines?**
- A. 1 year
 - B. 5 years
 - C. 7 years
 - D. 10 years
- 7. What is the minimum clearance required in front of a toilet in inches?**
- A. 18
 - B. 21
 - C. 15
 - D. 24
- 8. Which of the following is a characteristic of damp proofing?**
- A. Stops all moisture
 - B. Allows moisture vapor to escape
 - C. Requires no maintenance
 - D. Applied in a single coat
- 9. Which of the following is not an acceptable concrete or foundation waterproofing system?**
- A. 6 mil PVC
 - B. 60 mil Flexible Polymer Cement
 - C. Two-ply hot mopped felts
 - D. 3 mil PVC
- 10. What is the allowable shear in pounds for a 1 inch bolt embedded 21 inches into adobe masonry?**
- A. 300
 - B. 400
 - C. 500
 - D. 600

Answers

SAMPLE

1. A
2. B
3. B
4. C
5. C
6. C
7. C
8. B
9. D
10. B

SAMPLE

Explanations

SAMPLE

1. What is the minimum slope percentage for ground directly adjacent to the foundation?

- A. 2%**
- B. 5%
- C. 3%
- D. 10%

The minimum slope percentage for ground directly adjacent to a foundation is 2%. This requirement is set to ensure proper drainage away from the foundation, which is crucial for preventing water accumulation that can lead to structural issues such as cracking, settling, and moisture intrusion. A slope of 2% means that for every 100 units of horizontal distance, there should be a 2-unit drop in elevation. This gentle slope effectively directs rainwater and surface runoff away from the foundation, mitigating the risks associated with water erosion and foundation damage. Recognizing the importance of maintaining this slope can significantly contribute to the longevity and integrity of a building. While steeper slopes may provide better drainage, they can also pose challenges in certain landscaping and construction scenarios. A slope percentage less than 2% would not be sufficient to ensure that water drains away effectively, potentially leading to problems over time.

2. What is the maximum depth a stud in an exterior wall can be notched?

- A. 15 percent of width
- B. 20 percent of width**
- C. 25 percent of width
- D. 30 percent of width

Notching a stud is a common practice in construction, especially when dealing with wiring, plumbing, or other installations within walls. In the context of an exterior wall, it's crucial to adhere to safety and structural integrity standards. The maximum depth a stud can be notched is established to maintain the strength of the stud while allowing for necessary modifications. Notching more than the specified depth can compromise the stud's capacity to support loads, which could lead to structural failures over time. When the standard is set at 20 percent of the stud's width, it ensures that there remains a sufficient amount of material to support structural loads. This balances the necessity of making room for utilities with the need for maintaining the wall's structural integrity. In contrast, smaller or larger notch depths would either undermine the strength more than acceptable or be more conservative than typically required. Understanding these thresholds is essential for anyone involved in construction as it directly impacts building safety and compliance with building codes.

3. What is the maximum horizontal spacing interval for PVC hydronic piping?

- A. 2.67 feet
- B. 3 feet**
- C. 4 feet
- D. 6 feet

The maximum horizontal spacing interval for PVC hydronic piping is 3 feet. This measurement is crucial because it ensures proper support for the piping system and helps to prevent sagging or stress that could lead to damage over time. Maintaining this spacing helps to distribute the weight of the piping effectively and allows for thermal expansion and contraction without compromising the integrity of the piping material. This standard is typically in accordance with the manufacturer's specifications or building codes that govern piping installation practices. Observing the correct spacing helps ensure that the system operates efficiently and prolongs the life of the materials used.

4. How many screws are required to connect steel roof trusses to a load-bearing wall?

- A. 6
- B. 8
- C. 10**
- D. 12

The correct answer indicates that a total of 10 screws is required to securely connect steel roof trusses to a load-bearing wall. This number is derived from industry standards and best practices related to structural integrity and safety. In construction, ensuring that structural elements are adequately fastened is crucial for the stability of the building, especially in load-bearing applications. The specified number of screws is based on factors such as the weight of the truss, the materials being connected, and the potential loads that the connection will bear, including environmental factors like wind and snow. Using the proper number of screws not only helps to ensure a robust connection but also adheres to code regulations that are in place to protect the integrity of the structure. In this context, fewer screws may not provide sufficient holding power, while excessive screws could lead to unnecessary cost and material usage without added benefit. This is why the design often dictates a specific number, in this case, arriving at the conclusion that 10 screws offer the appropriate balance between strength and efficiency for connecting steel trusses to load-bearing walls.

5. Live loads on floors and roofs must be posted by the owner when they exceed ____ PSF.

- A. 25
- B. 30
- C. 50**
- D. 100

The requirement for posting live loads on floors and roofs is important for safety and structural integrity. When the live load exceeds 50 pounds per square foot (PSF), it indicates that the load on the structure could be significant and potentially hazardous if there are no warnings for occupants. Posting this information helps ensure that those using the building are aware of the maximum load capacity, which aids in preventing overloading that could lead to structural damage or catastrophic failure. Posting the load capacity below this threshold may not adequately address safety concerns, as lighter loads are generally less risky and can typically be accommodated without warning. The threshold of 50 PSF strikes a balance between safety and practicality, emphasizing the need for clear communication from the owner to all users of the space. This regulation is in place to promote awareness and compliance with safe usage practices in structures, particularly in commercial and public buildings.

6. How long must an employer keep employee records according to federal guidelines?

- A. 1 year
- B. 5 years
- C. 7 years**
- D. 10 years

Employers are required to keep employee records for a minimum of seven years according to federal guidelines. This duration helps ensure that all necessary documentation related to an employee's tenure at the company, including hiring records, wage records, and any other relevant employment documents, are available in case of audits or legal claims. Retaining records for this period allows employers to have adequate documentation to defend against potential accusations of misconduct or disputes regarding employment-related matters. Maintaining these records for seven years also aligns with various federal laws, including those that pertain to equal employment opportunity and wage and hour laws, which have specific documentation requirements. This timeframe is established to provide sufficient coverage for any potential legal claims that may arise, thereby protecting both the employer and the employee's rights and interests.

7. What is the minimum clearance required in front of a toilet in inches?

- A. 18
- B. 21
- C. 15**
- D. 24

The minimum clearance required in front of a toilet is established to ensure safety and accessibility for users. A clearance of 21 inches is commonly recognized as the standard requirement for proper spacing in front of a toilet. This distance allows enough room for individuals to comfortably use the toilet without feeling cramped or obstructed. In designing spaces such as bathrooms, following these clearance guidelines is essential not only for functionality but also for compliance with accessibility codes, making it easier for all individuals, including those with disabilities, to navigate the space safely. While 15 inches may be usable in some contexts, it does not meet the standard recommended clearance, which could lead to accessibility challenges. Similarly, while 24 inches provides additional space, it exceeds the minimum requirement and is not necessary for ensuring functionality. It's important to prioritize both safety and comfort in bathroom design, which underscores the necessity for adhering to the recommended minimum of 21 inches in front of a toilet.

8. Which of the following is a characteristic of damp proofing?

- A. Stops all moisture
- B. Allows moisture vapor to escape**
- C. Requires no maintenance
- D. Applied in a single coat

The characteristic of damp proofing that allows moisture vapor to escape is essential for the longevity and effectiveness of a structure. Damp proofing is designed to limit the passage of moisture in liquid form but does not completely seal off vapor. This ability to allow vapor to escape helps prevent the buildup of pressure, which could lead to damage within the walls or foundation over time. It is critical in environments where moisture is present but needs to be managed rather than entirely blocked. By permitting moisture vapor to escape, damp proofing contributes to maintaining the structural integrity and reducing conditions that could promote mold and decay. The other characteristics mentioned do not accurately describe damp proofing. For instance, while damp proofing significantly reduces moisture intrusion, it may not fully stop all moisture, particularly under severe conditions. Additionally, while damp proofing materials may require less frequent maintenance than other methods, they still may need inspections and potential touch-ups over time. Lastly, damp proofing applications can vary, as thickness and the method of application (single coat versus multiple coats) depend on the product used and the specific building requirements. Hence, the correct answer highlights an essential functional aspect of damp proofing that optimally balances moisture control with structural health.

9. Which of the following is not an acceptable concrete or foundation waterproofing system?

- A. 6 mil PVC
- B. 60 mil Flexible Polymer Cement
- C. Two-ply hot mopped felts
- D. 3 mil PVC**

The choice of 3 mil PVC as a concrete or foundation waterproofing system is not acceptable primarily due to its inadequate thickness for effective waterproofing. Generally, waterproofing membranes require a certain thickness to provide sufficient resistance against water infiltration and structural moisture issues. In contrast, other materials listed, such as 6 mil PVC, 60 mil Flexible Polymer Cement, and two-ply hot mopped felts, are recognized for their reliability and effectiveness in preventing moisture intrusion. These options typically have greater thickness or design features that allow them to handle the stresses and potential leaks associated with concrete structures. Selecting an appropriate waterproofing system is critical for ensuring the longevity of concrete and foundation structures, and in this case, the 3 mil PVC does not meet the required standards, making it unsuitable for such applications.

10. What is the allowable shear in pounds for a 1 inch bolt embedded 21 inches into adobe masonry?

- A. 300
- B. 400**
- C. 500
- D. 600

The allowable shear force for a concrete or masonry connection is often derived from standardized tables based on the type of materials and conditions involved. In this scenario, you are dealing with a 1-inch bolt embedded 21 inches into adobe masonry. The shear capacity of bolts can vary based on several design factors, including the material being used, the size of the bolt, and how deep the bolt is set into the material. For adobe masonry, the depth of embedment plays a critical role, as a deeper embedment generally provides better shear resistance. Furthermore, for a 1-inch bolt, industry standards or empirical data typically indicate a certain shear capacity based on tests or established guidelines. In this case, the appropriate reference for such masonry applications, potentially found in building codes or engineering handbooks, commonly cites an allowable shear load around 400 pounds for a 1-inch bolt in a well-defined application with specific embedment into adobe. Therefore, the selection of 400 pounds aligns with foundational engineering principles and established tables that dictate performance values for different materials and conditions, confirming it as the correct answer for the scenario given.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

<https://alabamacontractors.examzify.com>

We wish you the very best on your exam journey. You've got this!

SAMPLE