


NCTI SERVICE TECHNICIAN PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR
THE FULL VERSION STUDY GUIDE

<https://nctiservicetech.examzify.com>



Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright	1
Table of Contents	2
Introduction	3
How to Use This Guide	4
Questions	5
Answers	8
Explanations	10
Next Steps	16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

Questions

SAMPLE

- 1. Are the VOP factors for all types of cable greater or less than the VOP factor for RF signals in a vacuum?**
 - A. Greater
 - B. Less
 - C. Equal
 - D. Varies widely

- 2. What is the total cable loss at -40°F for a 2,200-foot 0.750-inch cable with a typical cable loss of 1.48 dB at 68°F?**
 - A. 10.50 dB
 - B. 20.04 dB
 - C. 29.04 dB
 - D. 38.00 dB

- 3. Why are silicon diodes preferred over germanium diodes?**
 - A. Silicon diodes have higher power ratings.
 - B. Silicon diodes are more thermally stable.
 - C. Germanium diodes are less expensive.
 - D. Silicon diodes are smaller in size.

- 4. What type of cable damage is commonly caused by severe weather?**
 - A. Cut cables from digging
 - B. Lightning strikes to aerial cables
 - C. Traffic accidents
 - D. General wear and tear

- 5. Which situation requires annual reporting according to FCC regulations?**
 - A. Periodic audits by in-house legal teams
 - B. Calculating the broadband cable plant's Cumulative Leakage Index
 - C. Establishing new business strategies for providers
 - D. Common practice in customer service training

- 6. What is the apparent effect of eddy currents on power consumption in conductors of AC circuits?**
- A. Eddy currents reduce losses
 - B. Eddy currents have no effect on power consumption
 - C. Eddy currents contribute to increased power consumption
 - D. Eddy currents improve conductor efficiency
- 7. How does multimode fiber differ from single-mode fiber?**
- A. Multimode fiber has a single path for light transmission
 - B. Single-mode fiber allows multiple paths through the core
 - C. Multimode fiber has less attenuation than single-mode
 - D. Single-mode fiber passes light through a single path
- 8. Why are taps with lower tap values preferred at greater distances from an amplifier?**
- A. To reduce costs of installation
 - B. To ensure adequate signal levels for customers
 - C. To improve amplifier performance
 - D. To limit the frequency range
- 9. What is the fixed output impedance of digital TDRs?**
- A. 50 Ω
 - B. 100 Ω
 - C. 75 Ω
 - D. 150 Ω
- 10. What is the typical frequency range of reverse RF output signals for a distribution amplifier?**
- A. 1-10 MHz
 - B. 5-42 MHz
 - C. 30-100 MHz
 - D. 50-200 MHz

Answers

SAMPLE

1. B
2. C
3. B
4. B
5. B
6. C
7. D
8. B
9. B
10. B

SAMPLE

Explanations

SAMPLE

1. Are the VOP factors for all types of cable greater or less than the VOP factor for RF signals in a vacuum?

- A. Greater
- B. Less**
- C. Equal
- D. Varies widely

The correct answer is that the VOP (Velocity of Propagation) factors for all types of cable are less than the VOP factor for RF signals in a vacuum. In a vacuum, the speed of light is approximately 299,792 kilometers per second, which represents the highest possible speed for RF signals. When RF signals travel through different types of cable, such as coaxial or fiber optic cables, they encounter various materials that impede the speed of propagation. These materials have different dielectric properties, which result in a slower speed compared to the propagation speed in a vacuum. Consequently, the VOP in cables is always less than that in a vacuum due to these inherent material characteristics. While there are variances in VOP based on the specific type of cable and its construction, all common types (like coaxial, twisted pair, and fiber optics) will have a VOP factor that is less than that of RF signals in a vacuum. Therefore, it is accurate to conclude that the VOP factors for all types of cable are consistently less than the VOP factor for RF signals in a vacuum.

2. What is the total cable loss at -40°F for a 2,200-foot 0.750-inch cable with a typical cable loss of 1.48 dB at 68°F?

- A. 10.50 dB
- B. 20.04 dB
- C. 29.04 dB**
- D. 38.00 dB

To determine the total cable loss at -40°F for a 2,200-foot 0.750-inch cable, it is necessary to consider how temperature affects cable loss. Cable loss is affected by various factors including temperature, where typically, loss increases as the temperature decreases. The typical cable loss is given as 1.48 dB at 68°F. To estimate the loss at a much lower temperature, like -40°F, one can apply an adjustment factor, which is often based on historical data or specifications from manufacturers about how much loss increases per degree of temperature change. While the specific adjustment factor isn't provided here, many resources indicate that for certain types of coaxial cables, cable loss can increase by about 0.01 dB per degree Fahrenheit decrease in temperature. Given the substantial temperature drop from 68°F to -40°F, this results in a significant increase in loss. For calculations: 1. First, convert the temperature difference to degrees. - The change in temperature is: 68°F - (-40°F) = 108°F 2. Now apply an estimated loss increase: - Using an example factor of 0.01 dB for each degree, the increase in loss would be approximately 1

3. Why are silicon diodes preferred over germanium diodes?

- A. Silicon diodes have higher power ratings.
- B. Silicon diodes are more thermally stable.**
- C. Germanium diodes are less expensive.
- D. Silicon diodes are smaller in size.

Silicon diodes are preferred over germanium diodes primarily due to their superior thermal stability. Silicon exhibits better performance in a wide range of temperatures, making it less susceptible to fluctuations that can affect the diode's operation. Unlike germanium, which has a smaller bandgap and can lead to leakage currents at higher temperatures, silicon maintains a more consistent performance and allows for operation at higher voltages and temperatures without the risk of thermal runaway. Manufacturing processes also favor silicon due to its abundance and operational characteristics, which results in silicon diodes often being more reliable in various applications. For example, in power electronics and conditions where temperature changes might occur, silicon diodes are favored because they can withstand these variations without degradation in performance. While silicon diodes certainly have higher power ratings and smaller physical dimensions in some cases, their reliability and stability under different thermal conditions make them the preferred choice over germanium diodes in most applications.

4. What type of cable damage is commonly caused by severe weather?

- A. Cut cables from digging
- B. Lightning strikes to aerial cables**
- C. Traffic accidents
- D. General wear and tear

Severe weather, especially events such as thunderstorms, can lead to lightning strikes, which pose a significant risk to aerial cables. When lightning strikes, it can cause severe damage to these cables, including melting insulation, creating breaks, or disrupting the signal integrity. This type of damage is particularly concerning in areas with frequent thunderstorms, where the risk of lightning strikes increases significantly. While other types of cable damage can occur from various sources—like physical cuts from digging, traffic accidents, or general wear and tear—these are not directly caused by severe weather events. Lightning strikes specifically highlight the impact of weather-related phenomena on infrastructure, making it a prominent concern for maintaining the integrity of aerial communication lines.

5. Which situation requires annual reporting according to FCC regulations?

- A. Periodic audits by in-house legal teams
- B. Calculating the broadband cable plant's Cumulative Leakage Index**
- C. Establishing new business strategies for providers
- D. Common practice in customer service training

The requirement for annual reporting according to FCC regulations is specifically tied to monitoring and mitigating signal leakage in broadband cable plants. The Cumulative Leakage Index (CLI) is a critical metric used to assess the level of signal leakage from a cable system, which can lead to interference and violate FCC standards. The CLI calculation helps ensure that the cable company's infrastructure complies with mandated thresholds, thus safeguarding the integrity of broadcasting services and minimizing interference with other communications systems. This aspect of compliance is directly regulated by the FCC, necessitating that operators perform and report their findings on signal leakage regularly—typically on an annual basis—to maintain operating permits and avoid penalties. Maintaining a low CLI is not only important for operational efficiency but also for adhering to legal obligations set forth by the FCC. This focus on technical compliance distinguishes this situation from other choices, which relate to internal processes or customer service strategies and do not carry the same regulatory reporting requirements.

6. What is the apparent effect of eddy currents on power consumption in conductors of AC circuits?

- A. Eddy currents reduce losses
- B. Eddy currents have no effect on power consumption
- C. Eddy currents contribute to increased power consumption**
- D. Eddy currents improve conductor efficiency

Eddy currents are loops of electric current that are induced within conductors when they are exposed to a changing magnetic field, such as in alternating current (AC) circuits. These currents flow in a direction opposite to the applied electromagnetic field, leading to various effects on power consumption. When eddy currents form, they create additional resistance within the conductor, dissipating energy in the form of heat. This results in increased power consumption, as more energy is required to maintain the same level of current flow due to the losses associated with these currents. Essentially, the presence of eddy currents is detrimental to the efficiency of the conductive material, as they lead to additional power loss in the system. In the context of AC circuits, where currents frequently change direction, eddy currents can be more prominent, therefore confirming that they indeed contribute to increased power consumption. The increase in energy lost as heat directly correlates to the efficiency of the conductor, illustrating how crucial it is to consider their impact in circuit design and applications. This understanding helps technicians optimize systems to mitigate eddy current losses, improving overall efficiency.

7. How does multimode fiber differ from single-mode fiber?

- A. Multimode fiber has a single path for light transmission
- B. Single-mode fiber allows multiple paths through the core
- C. Multimode fiber has less attenuation than single-mode
- D. Single-mode fiber passes light through a single path**

Multimode fiber and single-mode fiber have distinct characteristics based on how they transmit light signals. Single-mode fiber is designed to carry light directly down the fiber core, which has a smaller diameter, allowing only one mode or path of light to propagate. This single path minimizes signal attenuation and modal dispersion, making it suitable for long-distance communication. In contrast, multimode fiber has a larger core diameter, which permits multiple light modes to travel through simultaneously. This can result in increased modal dispersion over long distances, making multimode less effective for transmitting data over large spans compared to single-mode fiber. Option D highlights the key feature of single-mode fiber: it indeed passes light through a single path, which is the main advantage that allows for long-distance transmission with lower attenuation compared to multimode fiber. Understanding this fundamental difference is crucial for technicians when deciding which type of fiber to use for specific applications.

8. Why are taps with lower tap values preferred at greater distances from an amplifier?

- A. To reduce costs of installation
- B. To ensure adequate signal levels for customers**
- C. To improve amplifier performance
- D. To limit the frequency range

Taps with lower tap values are preferred at greater distances from an amplifier primarily to ensure adequate signal levels for customers. As signals travel over longer distances through coaxial cables or other transmission mediums, they tend to attenuate, meaning their strength decreases. Using taps with lower values allows less signal to be extracted from the cable. At greater distances, this is beneficial, as it prevents excessive signal loss and ensures that customers receive a signal that is within acceptable levels for optimal performance. By maintaining a balance between signal strength and distance, service providers can ensure a high-quality connection for users furthest from the amplifier, which is crucial for maintaining service standards. The other options may not align with the primary reason for using lower tap values at distances from the amplifier: reducing installation costs, improving amplifier performance, or limiting frequency range are not the central concerns of adjusting tap values in this particular scenario.

9. What is the fixed output impedance of digital TDRs?

- A. 50 Ω
- B. 100 Ω**
- C. 75 Ω
- D. 150 Ω

Digital Time Domain Reflectometers (TDRs) are essential tools used for measuring the impedance and identifying faults in transmission lines, such as coaxial cables and twisted pairs. The fixed output impedance of digital TDRs is typically standardized to 100 Ω . This standardization is important because it allows TDRs to provide accurate measurements and effective reflections from the cable being tested. When facing a transmission line, if the TDR has an output impedance that matches the characteristic impedance of the line, the reflections will be minimized and the readings will be accurate. In many telecommunications and networking applications, a 100 Ω impedance is commonly found, particularly in balanced cabling systems like twisted pair used in Ethernet and other communication standards. This is why the fixed output impedance of digital TDRs is set at 100 Ω to ensure compatibility and precise measurements in these environments.

10. What is the typical frequency range of reverse RF output signals for a distribution amplifier?

A. 1-10 MHz

B. 5-42 MHz

C. 30-100 MHz

D. 50-200 MHz

The typical frequency range of reverse RF output signals for a distribution amplifier is indeed 5-42 MHz. This range is specifically relevant because it aligns with the frequencies used for upstream communications in many cable systems, where signals are sent from the user back to the service provider. The 5-42 MHz range is vital for applications such as data services (including cable modems) and other return signal functions. When working with reverse RF signals, the distribution amplifier is designed to ensure that these signals can maintain sufficient strength and integrity as they travel back through the system to avoid any loss of communication quality. This range facilitates reliable transmission of upstream data, which is crucial for maintaining effective network performance. Understanding this frequency range helps technicians in setting up and troubleshooting distribution amplifiers to ensure optimal signal quality within the operational parameters of the network.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

<https://nctiservicetech.examzify.com>

We wish you the very best on your exam journey. You've got this!

SAMPLE