


TEXAS WASTEWATER CLASS A PRACTICE EXAM (SAMPLE)

STUDY GUIDE



SAMPLE STUDY GUIDE WITH LIMITED QUESTIONS

VISIT US ONLINE FOR
THE FULL VERSION STUDY GUIDE

<https://txwastewaterclassa.examzify.com>



Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright	1
Table of Contents	2
Introduction	3
How to Use This Guide	4
Questions	5
Answers	8
Explanations	10
Next Steps	16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 – 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

Questions

SAMPLE

- 1. What is the primary requirement for documenting compliance with the Hazard Communication Act?**
 - A. Safety Data Sheets
 - B. Employee training logs
 - C. Chemical inventory list
 - D. Compliance audits
- 2. What is a characteristic property of grease that contributes to blockages in wastewater systems?**
 - A. Low viscosity
 - B. High solubility
 - C. Ability to harden
 - D. High density
- 3. In Texas, when is disinfection of treated effluent not required?**
 - A. When detention time is less than 7 days
 - B. When detention time is 21 days or more
 - C. When treated effluent is under 10,000 gallons
 - D. When the temperature exceeds 100 degrees Fahrenheit
- 4. What can a high percentage of solids in sludge indicate?**
 - A. Effective treatment processes
 - B. Potential operational issues
 - C. Consistent flow rates
 - D. Low nutrient levels
- 5. What adjustment should be made to the spacing of barricades as roadway speed increases on a construction job site?**
 - A. Decrease
 - B. Remain the same
 - C. Increase
 - D. Vary randomly

- 6. What is a significant hazard associated with the use of powdered activated carbon?**
- A. Corrosive reactions
 - B. Fire/explosive risks
 - C. Electrical hazards
 - D. Biological contamination
- 7. What is the purpose of reducing BOD in wastewater treatment?**
- A. To increase nutrient levels
 - B. To protect aquatic life
 - C. To enhance pH levels
 - D. To increase sludge volume
- 8. Which of the following factors is NOT typically evaluated in a construction site safety checklist?**
- A. Placement of flaggers and barricades
 - B. Type of construction materials
 - C. Placement of vehicles
 - D. Use of warning signs
- 9. The sludge from a primary clarifier typically contains what percent solids?**
- A. 2% to 3%
 - B. 4% to 6%
 - C. 7% to 8%
 - D. 9% to 10%
- 10. What is the velocity of water flowing through a clarifier if the flow is 5,837 gpm?**
- A. 0.02 fps
 - B. 0.5 fps
 - C. 1.0 fps
 - D. 0.1 fps

Answers

SAMPLE

1. A
2. C
3. B
4. B
5. C
6. B
7. B
8. B
9. B
10. A

SAMPLE

Explanations

SAMPLE

1. What is the primary requirement for documenting compliance with the Hazard Communication Act?

- A. Safety Data Sheets**
- B. Employee training logs
- C. Chemical inventory list
- D. Compliance audits

The primary requirement for documenting compliance with the Hazard Communication Act is Safety Data Sheets (SDS). These documents are essential because they provide detailed information about every hazardous chemical used in the workplace. The SDS must include information on the properties of each chemical, health hazards, protective measures, and safety precautions for handling, storing, and transporting the chemicals. Having correct and accessible SDS is crucial for ensuring that employees are informed about the potential hazards they may encounter and the appropriate measures to protect themselves. This aligns with the overarching goal of the Hazard Communication Act, which is to ensure that information regarding the hazards and safe handling of chemicals is effectively communicated to workers. While employee training logs, chemical inventory lists, and compliance audits are important components in the overall management of hazardous substances, they serve as supplementary documentation rather than the primary requirement. The SDS fundamentally supports the effective communication of hazard information, making it the cornerstone of compliance with the Act.

2. What is a characteristic property of grease that contributes to blockages in wastewater systems?

- A. Low viscosity
- B. High solubility
- C. Ability to harden**
- D. High density

The characteristic property of grease that contributes to blockages in wastewater systems is its ability to harden. Grease is composed of fats and oils that can solidify as they cool down or when they are subjected to certain conditions, such as the temperature fluctuations often found in sewer systems. When grease hardens, it can cling to the walls of pipes, accumulating over time and forming significant blockages that impede the flow of wastewater. This property creates a significant challenge in wastewater management because these hardened deposits are difficult to remove and can lead to backups, overflows, and costly maintenance issues. Unlike substances that have low viscosity or high solubility, which would either flow easily or dissolve in water, greasy substances that harden can become solid and persist in the sewage system, causing ongoing operational problems.

3. In Texas, when is disinfection of treated effluent not required?

- A. When detention time is less than 7 days
- B. When detention time is 21 days or more**
- C. When treated effluent is under 10,000 gallons
- D. When the temperature exceeds 100 degrees Fahrenheit

In Texas, disinfection of treated effluent is typically not required when the detention time is 21 days or more. This is based on the understanding that longer detention times allow for natural processes, such as sedimentation and microbial activities, to reduce pathogens and improve water quality. During this extended period, the effluent can undergo significant treatment through natural die-off of harmful microorganisms, thus decreasing the need for additional disinfection measures. Detention times shorter than 21 days may not allow sufficient natural attenuation of pathogens, which is why disinfection would still be necessary for those scenarios. Additionally, the size of the treated effluent volume and temperature do not directly relate to the requirement for disinfection in the same manner as the detention time does. In conclusion, the prolonged detention period provides adequate opportunity for the effluent to become cleaner, reducing or eliminating the necessity for further disinfection.

4. What can a high percentage of solids in sludge indicate?

- A. Effective treatment processes
- B. Potential operational issues**
- C. Consistent flow rates
- D. Low nutrient levels

A high percentage of solids in sludge typically indicates potential operational issues within the wastewater treatment process. When sludge contains a high concentration of solids, it may suggest that there is a problem with the treatment system, such as inadequate digestion or insufficient mixing. This scenario can result in operational difficulties, such as increased burden on the dewatering process or challenges in achieving effective waste stabilization. Furthermore, elevated solid levels can lead to increased costs and reduced efficiency in the treatment process. It's essential to monitor and manage sludge characteristics to maintain optimal operational performance. In contrast, effective treatment processes would typically result in lower solid concentrations due to successful breakdown and stabilization of organic materials. Consistent flow rates and low nutrient levels are not directly related to the presence of high solids in sludge, thereby making them less relevant in this context.

5. What adjustment should be made to the spacing of barricades as roadway speed increases on a construction job site?

- A. Decrease
- B. Remain the same
- C. Increase**
- D. Vary randomly

As roadway speed increases on a construction job site, it is important to adjust the spacing of barricades to ensure the safety of both workers and drivers. Increasing the spacing of barricades allows for adequate reaction time for drivers who may need to navigate through or around the construction zone at higher speeds. When drivers are traveling faster, their stopping distance increases, meaning they need more time and distance to perceive hazards and react appropriately. By providing greater spacing between barricades, it helps maintain visibility and ensures that drivers can clearly see the construction area in sufficient time to slow down or change lanes safely. This practice aligns with safety standards that prioritize the protection of both road users and construction personnel. In contrast, maintaining the same spacing or decreasing it would not respond effectively to the increased risks associated with higher roadway speeds, potentially leading to dangerous situations. Random variations in spacing would introduce further confusion and risk, making it harder for drivers to navigate the area safely.

6. What is a significant hazard associated with the use of powdered activated carbon?

- A. Corrosive reactions
- B. Fire/explosive risks**
- C. Electrical hazards
- D. Biological contamination

The significant hazard associated with the use of powdered activated carbon is fire/explosive risks. This is due to the fact that powdered activated carbon is a fine, combustible substance. When particulate matter is suspended in air, it can create a flammable dust cloud that poses an explosion hazard. If the concentration of carbon dust in the air reaches a certain level and is ignited by a spark or heat source, it can lead to a fast and intense combustion process. In the context of wastewater treatment processes, where activated carbon is often used for adsorption of contaminants, it is crucial to manage the storage and handling of fine powders safely to minimize the chances of creating potential fire hazards. Proper ventilation, grounding equipment to prevent static electricity buildup, and using protective measures when handling the material are essential safety practices to mitigate these risks. Understanding the nature of powdered activated carbon not only informs safety protocols but also emphasizes the importance of proper operational procedures to ensure a safe working environment for all personnel.

7. What is the purpose of reducing BOD in wastewater treatment?

- A. To increase nutrient levels
- B. To protect aquatic life**
- C. To enhance pH levels
- D. To increase sludge volume

The purpose of reducing Biochemical Oxygen Demand (BOD) in wastewater treatment primarily focuses on protecting aquatic life. BOD is a measure of the amount of oxygen that microorganisms will consume while decomposing organic matter in water. High BOD levels indicate a significant amount of organic pollution, which can lead to depleted oxygen levels in water bodies. This depletion can create hostile environments for aquatic organisms, leading to stress or death of fish and other aquatic species. By reducing BOD through treatment processes, the amount of organic material in the water is decreased, allowing oxygen levels to remain adequate for sustaining healthy aquatic ecosystems. While increasing nutrient levels, enhancing pH, or increasing sludge volume may be relevant in specific contexts, they do not address the fundamental environmental and ecological goal of wastewater treatment, which is to mitigate harmful effects on aquatic life resulting from untreated or poorly treated wastewater. Therefore, protecting aquatic life is the core objective in reducing BOD levels.

8. Which of the following factors is NOT typically evaluated in a construction site safety checklist?

- A. Placement of flaggers and barricades
- B. Type of construction materials**
- C. Placement of vehicles
- D. Use of warning signs

In a construction site safety checklist, the key focus is on ensuring safe operations and minimizing hazards that could affect workers and the public. Factors such as the placement of flaggers and barricades, the placement of vehicles, and the use of warning signs are all critical components that directly relate to site safety. These elements help manage traffic flow, prevent accidents, and ensure that both workers and bystanders are aware of construction activities and potential dangers. On the other hand, while the type of construction materials may impact other aspects of a construction project, including structural integrity and compliance with building codes, it is not typically a primary concern in relation to immediate safety protocols at the construction site. Safety checklists are more focused on operational procedures than on the materials themselves. Thus, the evaluation of construction materials is less relevant to the day-to-day safety measures that a checklist is designed to address.

9. The sludge from a primary clarifier typically contains what percent solids?

- A. 2% to 3%
- B. 4% to 6%**
- C. 7% to 8%
- D. 9% to 10%

The correct answer indicates that the sludge from a primary clarifier typically contains 4% to 6% solids. This range is representative of the concentration of solids that accumulates during the primary treatment phase of wastewater treatment, where heavy solids settle out of the liquid due to gravity. In a primary clarifier, wastewater is allowed to stand to enable solids to settle, thereby separating out a significant amount of the suspended material. The settled solids, referred to as primary sludge, usually have a solid content that falls within this specific percentage range. This concentration is critical for subsequent treatment processes, as it impacts the design and operation of the treatment plant. The values provided for the other ranges either underestimate or overestimate the typical solid concentration found in primary sludge. This specificity is essential for operators to understand, as it helps in calculating treatment requirements and managing the overall efficiency of the wastewater treatment system.

10. What is the velocity of water flowing through a clarifier if the flow is 5,837 gpm?

- A. 0.02 fps**
- B. 0.5 fps
- C. 1.0 fps
- D. 0.1 fps

*To determine the velocity of water flowing through a clarifier from the flow rate in gallons per minute (gpm), it's essential to convert the flow rate into a velocity measurement. The flow rate of 5,837 gpm can be converted to feet per second (fps) using the following formula: 1. **Convert gpm to cubic feet per second (cfs):** Since there are 7.48 gallons in a cubic foot, we can convert 5,837 gpm to cfs by using the conversion factor.
$$\text{cfs} = \frac{\text{gpm}}{448.831}$$
 where 448.831 is the number of gallons in a cubic foot per minute. Performing the calculation:
$$\frac{5,837}{448.831} \approx 13.0 \text{ cfs}$$
 2. **Calculate the cross-sectional area of the clarifier:** To find the velocity, the cross-sectional area of the clarifier must be known (for instance, in square feet). Assuming a typical area for calculations (which would need to be provided*

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

<https://txwastewaterclassa.examzify.com>

We wish you the very best on your exam journey. You've got this!

SAMPLE