

Wisconsin Plumbing Practice Test (Sample)

Study Guide



Everything you need from our exam experts!

Copyright © 2026 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain accurate, complete, and timely information about this product from reliable sources.

SAMPLE

Table of Contents

Copyright	1
Table of Contents	2
Introduction	3
How to Use This Guide	4
Questions	5
Answers	8
Explanations	10
Next Steps	16

SAMPLE

Introduction

Preparing for a certification exam can feel overwhelming, but with the right tools, it becomes an opportunity to build confidence, sharpen your skills, and move one step closer to your goals. At Examzify, we believe that effective exam preparation isn't just about memorization, it's about understanding the material, identifying knowledge gaps, and building the test-taking strategies that lead to success.

This guide was designed to help you do exactly that.

Whether you're preparing for a licensing exam, professional certification, or entry-level qualification, this book offers structured practice to reinforce key concepts. You'll find a wide range of multiple-choice questions, each followed by clear explanations to help you understand not just the right answer, but why it's correct.

The content in this guide is based on real-world exam objectives and aligned with the types of questions and topics commonly found on official tests. It's ideal for learners who want to:

- Practice answering questions under realistic conditions,
- Improve accuracy and speed,
- Review explanations to strengthen weak areas, and
- Approach the exam with greater confidence.

We recommend using this book not as a stand-alone study tool, but alongside other resources like flashcards, textbooks, or hands-on training. For best results, we recommend working through each question, reflecting on the explanation provided, and revisiting the topics that challenge you most.

Remember: successful test preparation isn't about getting every question right the first time, it's about learning from your mistakes and improving over time. Stay focused, trust the process, and know that every page you turn brings you closer to success.

Let's begin.

How to Use This Guide

This guide is designed to help you study more effectively and approach your exam with confidence. Whether you're reviewing for the first time or doing a final refresh, here's how to get the most out of your Examzify study guide:

1. Start with a Diagnostic Review

Skim through the questions to get a sense of what you know and what you need to focus on. Your goal is to identify knowledge gaps early.

2. Study in Short, Focused Sessions

Break your study time into manageable blocks (e.g. 30 - 45 minutes). Review a handful of questions, reflect on the explanations.

3. Learn from the Explanations

After answering a question, always read the explanation, even if you got it right. It reinforces key points, corrects misunderstandings, and teaches subtle distinctions between similar answers.

4. Track Your Progress

Use bookmarks or notes (if reading digitally) to mark difficult questions. Revisit these regularly and track improvements over time.

5. Simulate the Real Exam

Once you're comfortable, try taking a full set of questions without pausing. Set a timer and simulate test-day conditions to build confidence and time management skills.

6. Repeat and Review

Don't just study once, repetition builds retention. Re-attempt questions after a few days and revisit explanations to reinforce learning. Pair this guide with other Examzify tools like flashcards, and digital practice tests to strengthen your preparation across formats.

There's no single right way to study, but consistent, thoughtful effort always wins. Use this guide flexibly, adapt the tips above to fit your pace and learning style. You've got this!

Questions

SAMPLE

- 1. What is the minimum bottom diameter for a storm sump?**
 - A. 12 inches**
 - B. 14 inches**
 - C. 16 inches**
 - D. 18 inches**

- 2. Under operating conditions, a grease interceptor may not be located in an area where surrounding temperatures are below what threshold?**
 - A. Below 40°F**
 - B. Below 32°F**
 - C. Below 50°F**
 - D. Below 60°F**

- 3. Stormwater gravity drains may be combined with clearwater drains prior to discharging to the storm building drain only if approved by the department.**
 - A. They may be combined, but only with approval by the department.**
 - B. They may be combined at any time.**
 - C. They may not be combined prior to discharging to the storm building drain, unless approved.**
 - D. They must always be kept separate.**

- 4. What is the minimum separation distance between a water well and a school well?**
 - A. 100 feet**
 - B. 250 feet**
 - C. 150 feet**
 - D. 300 feet**

- 5. What is the minimum dimension for manhole openings?**
 - A. 19 inches**
 - B. 21 inches**
 - C. 25 inches**
 - D. 23 inches**

- 6. Which floor levels are used to determine the building drain elevation?**
- A. The lowest floor outside the building.**
 - B. The lowest floor levels on which fixtures may be installed.**
 - C. The highest floor levels on which fixtures may be installed.**
 - D. The grade level at the street.**
- 7. Test methods for drain and vent systems require what?**
- A. 10 feet head of water; air test with a uniform gauge pressure of 5 PSI or sufficient to balance a mercury column 10 inches high; hold for 15 minutes.**
 - B. 15 feet head of water; air test with 2 PSI; hold 5 minutes.**
 - C. 5 feet head of water; air test with 10 PSI; hold 30 minutes.**
 - D. 20 feet head of water; vacuum test; hold 60 minutes.**
- 8. What is the maximum horizontal length allowed for indirect waste piping and local waste piping handling sanitary wastes?**
- A. 30 feet**
 - B. 20 feet**
 - C. 40 feet**
 - D. 50 feet**
- 9. On a simplex pumping system, what alternative may be provided instead of the specified duplex pumping equipment?**
- A. Two-day holding capacity**
 - B. No alarm**
 - C. One-day holding capacity above a high level alarm**
 - D. Automatic pump cycling**
- 10. Which of the following best defines a horizontal reference point?**
- A. A movable marker used during construction for alignment.**
 - B. The highest point in the plumbing system.**
 - C. The vertical line marking ground level for elevations.**
 - D. A stationary identifiable point to which horizontal dimensions can be related.**

Answers

SAMPLE

1. B
2. A
3. C
4. B
5. D
6. C
7. A
8. A
9. C
10. D

SAMPLE

Explanations

SAMPLE

1. What is the minimum bottom diameter for a storm sump?

- A. 12 inches
- B. 14 inches**
- C. 16 inches
- D. 18 inches

A storm sump must provide enough interior space for maintenance and the installed pumping equipment, so codes set a minimum bottom diameter to ensure service access and proper function. Fourteen inches is the smallest diameter that meets that requirement. It gives room to install and service the sump pump and fittings and reduces the chance of frequent clogs or clearance issues. A smaller diameter, like twelve inches, would be too cramped for typical equipment and maintenance access. Larger sizes, such as sixteen or eighteen inches, would also work and meet the minimum, but they're not the smallest allowed.

2. Under operating conditions, a grease interceptor may not be located in an area where surrounding temperatures are below what threshold?

- A. Below 40°F**
- B. Below 32°F
- C. Below 50°F
- D. Below 60°F

Ambient temperature affects how a grease interceptor functions. When the surrounding area gets cold, fats and oils in the wastewater can begin to solidify or thicken, and solids may cling to the interior surfaces. This makes the trap less effective at separating grease, increases maintenance needs, and raises the risk of blockages and odors. To keep the device performing as intended, it should be located in a space that stays above that cold threshold, preventing grease from hardening and reducing the chance of freezing in the trap and pipes. That's why it's not placed in areas that get too cold. The other temperature ranges described would not pose the same risk of grease solidification or freezing to the same degree.

3. Stormwater gravity drains may be combined with clearwater drains prior to discharging to the storm building drain only if approved by the department.
- A. They may be combined, but only with approval by the department.
 - B. They may be combined at any time.
 - C. They may not be combined prior to discharging to the storm building drain, unless approved.**
 - D. They must always be kept separate.

The test is about keeping stormwater and clearwater drains separate unless there's explicit authorization to mix them. Stormwater and clearwater are treated as two streams that discharge toward the storm building drain, and mixing them can create capacity, backflow, or contamination issues, so any joining before discharge is tightly controlled. Therefore, the correct idea is that you generally cannot combine these drains prior to discharging to the storm building drain unless the department approves. This matches the conditional allowance—only with official approval may the two drains be combined. Choices that imply mixing could occur freely or that separation is mandatory without any approved exception aren't aligned with how the rule is applied.

4. What is the minimum separation distance between a water well and a school well?
- A. 100 feet
 - B. 250 feet**
 - C. 150 feet
 - D. 300 feet

Keeping wells far enough apart reduces the chance that contaminants or changes in groundwater flow around one well will affect the other, and it also minimizes interference between the wells' draw zones. In Wisconsin practice, the minimum separation distance between a water well and a school well is 250 feet, which provides a buffer so surface or subsurface contamination sources near the school aren't able to impact the other well, and so each well can reliably produce drinking water without shared contamination risks. If wells are closer, overlapping capture zones and faster potential transport paths increase the risk of cross-contamination and variability in water quality.

5. What is the minimum dimension for manhole openings?
- A. 19 inches
 - B. 21 inches
 - C. 25 inches
 - D. 23 inches**

Access openings must be large enough to allow safe entry and for cleaning and inspection tools to pass through. The standard sets the smallest allowable opening at 23 inches, providing enough clearance for a worker to maneuver and for equipment to fit without getting stuck. Anything smaller would hinder access and risk safety or code compliance. Larger openings, like 25 inches, are allowed but are not the minimum requirement, so 23 inches is the correct minimum.

6. Which floor levels are used to determine the building drain elevation?

- A. The lowest floor outside the building.**
- B. The lowest floor levels on which fixtures may be installed.**
- C. The highest floor levels on which fixtures may be installed.**
- D. The grade level at the street.**

Gravity drainage inside a building must have a continuous downward slope toward the building drain, so the drain's elevation is set with respect to the highest point from which wastewater could originate. That highest floor level where fixtures may be installed determines how high the interior drain must be able to receive and carry waste by gravity. If the building drain were placed too high, fixtures on lower floors could still drain, but fixtures on the top floor would have insufficient slope to reach the drain without pumping, which is not allowed in gravity systems. By aligning the building drain elevation with the topmost potential fixture level, all lower fixtures can discharge by gravity along proper slopes. The exterior grade at the street or the lowest exterior floor don't govern the interior drain elevation.

7. Test methods for drain and vent systems require what?

- A. 10 feet head of water; air test with a uniform gauge pressure of 5 PSI or sufficient to balance a mercury column 10 inches high; hold for 15 minutes.**
- B. 15 feet head of water; air test with 2 PSI; hold 5 minutes.**
- C. 5 feet head of water; air test with 10 PSI; hold 30 minutes.**
- D. 20 feet head of water; vacuum test; hold 60 minutes.**

Drain and vent tests rely on applying a known pressure to the piping so leaks will become evident. The standard approach uses a water column or an air pressure test to create a hydrostatic load that joints must withstand. Using a 10-foot head of water provides a realistic, code-recognized hydrostatic pressure (about 4.3 psi), and an air test at 5 psi—equivalent to balancing roughly 10 inches of mercury—plus holding that pressure for about 15 minutes gives enough time for any leaks to show up. This combination aligns with common testing requirements and keeps the test within safe, practical limits for typical drainage systems. The other options aren't as appropriate because they deviate from these standard conditions: the pressures or times aren't the commonly specified ones, or a vacuum test isn't the typical method used for drain and vent system testing.

8. What is the maximum horizontal length allowed for indirect waste piping and local waste piping handling sanitary wastes?

- A. 30 feet**
- B. 20 feet**
- C. 40 feet**
- D. 50 feet**

A key idea in indirect and local waste piping is that the discharge path must stay within a limited horizontal distance so venting can effectively protect traps and keep flow reliable. Limiting the run helps ensure the indirect waste receptor and its venting are close enough to the fixture to prevent siphonage, reduce the chance of solids building up, and minimize odors or backflow risk. The maximum allowed horizontal length for these waste takes is 30 feet. Shorter runs are fine, but anything longer would require additional venting or a different arrangement to maintain proper drainage. The other options would exceed or not reflect this limit, which is why 30 feet is the correct maximum.

9. On a simplex pumping system, what alternative may be provided instead of the specified duplex pumping equipment?

- A. Two-day holding capacity**
- B. No alarm**
- C. One-day holding capacity above a high level alarm**
- D. Automatic pump cycling**

Redundancy and alerting are the ideas behind this question. In a simplex pumping setup, you can substitute for a second pump by giving the system a defined storage buffer plus an alarm to warn before an overflow. Providing one day of holding capacity above a high-level alarm means there's enough room to store wastewater for a full day while the pump is down or during a period of high demand, and the alarm alerts you to take action before the level reaches a dangerous point. This combination mirrors the reliability a duplex system would offer, but using storage capacity and a warning rather than a second pump. Two-day holding capacity would exceed typical requirements and isn't the standard alternative. No alarm removes crucial warning that an overflow is imminent. Automatic pump cycling describes a different control strategy and doesn't inherently provide the same backup capability a second pump or a sufficient holding buffer with an alarm would.

10. Which of the following best defines a horizontal reference point?

- A. A movable marker used during construction for alignment.**
- B. The highest point in the plumbing system.**
- C. The vertical line marking ground level for elevations.**
- D. A stationary identifiable point to which horizontal dimensions can be related.**

A horizontal reference point is a fixed, identifiable spot used as a baseline for all horizontal measurements in a layout. Because it stays in place, measurements taken from it remain consistent across plans and on the job site, helping you accurately locate pipes, fittings, and fixtures in the horizontal plane. Distinct from vertical references (which relate to elevations) and from movable markers (which can shift and spoil accuracy), this point provides a stable origin for horizontal dimensions. So, the defining idea is that it's a stationary identifiable point to which horizontal measurements can be related.

SAMPLE

Next Steps

Congratulations on reaching the final section of this guide. You've taken a meaningful step toward passing your certification exam and advancing your career.

As you continue preparing, remember that consistent practice, review, and self-reflection are key to success. Make time to revisit difficult topics, simulate exam conditions, and track your progress along the way.

If you need help, have suggestions, or want to share feedback, we'd love to hear from you. Reach out to our team at hello@examzify.com.

Or visit your dedicated course page for more study tools and resources:

<https://wisconsinplumbing.examzify.com>

We wish you the very best on your exam journey. You've got this!

SAMPLE