

Connecticut CDL Combination Vehicles Permit Practice Test (Sample)

Study Guide



Everything you need from our exam experts!

Copyright © 2025 by Examzify - A Kaluba Technologies Inc. product.

ALL RIGHTS RESERVED.

No part of this book may be reproduced or transferred in any form or by any means, graphic, electronic, or mechanical, including photocopying, recording, web distribution, taping, or by any information storage retrieval system, without the written permission of the author.

Notice: Examzify makes every reasonable effort to obtain from reliable sources accurate, complete, and timely information about this product.

SAMPLE

Questions

- 1. What happens if the emergency air line breaks or gets pulled while driving?**
 - A. The tractor will stall**
 - B. The emergency trailer brakes will engage**
 - C. The service brakes will engage**
 - D. The trailer will detach**
- 2. What does the "no zone" refer to?**
 - A. The area around the vehicle where drivers can see clearly**
 - B. The blind spots around the vehicle where the driver cannot see**
 - C. The zone for parking regulations**
 - D. The area required for safe following distance**
- 3. What action should you take if the trailer begins to fishtail?**
 - A. Increase speed to pull it back into line**
 - B. Slam on the brakes to stop**
 - C. Slow down and steer in the direction of the skid**
 - D. Turn the steering wheel sharply**
- 4. What should be done if you experience braking issues while driving a combination vehicle?**
 - A. Continue driving to the nearest repair shop**
 - B. Stop the vehicle immediately and inspect the brakes**
 - C. Use engine braking to compensate**
 - D. Reduce speed and hope the brakes will improve**
- 5. If transporting hazardous materials, what additional requirement must you satisfy?**
 - A. You need a specialized trailer**
 - B. You must have a Hazardous Materials endorsement on your CDL**
 - C. You must notify all passengers**
 - D. You need to drive at a lower speed limit**

- 6. What is the potential outcome of not securing the crank handle after raising the iron trailer supports?**
- A. The supports may fall off during transit**
 - B. The trailer may become unstable**
 - C. The crank handle may become inaccessible**
 - D. The vehicle will not start**
- 7. What is the proper way to back up a combination vehicle?**
- A. Back up without checking surroundings**
 - B. Always use a spotter when possible and check surroundings frequently**
 - C. Back up only when necessary**
 - D. Use the rearview camera only**
- 8. What is the consequence of failing to adjust the brakes?**
- A. Increased fuel consumption**
 - B. Brakes may fail**
 - C. Higher vehicle speed**
 - D. Improved handling**
- 9. What does it indicate if the fifth wheel locking lever is not locked after the jaws close around the kingpin?**
- A. The coupling is secure and ready**
 - B. The coupling is not proper and needs adjustment**
 - C. The kingpin is damaged**
 - D. No action is required**
- 10. What happens if a driver crosses the air lines when hiking up to an old trailer without spring brakes?**
- A. The driver will be unable to start the vehicle**
 - B. The trailer brakes will function normally**
 - C. The driver can drive away but will lack trailer brakes**
 - D. The vehicle will automatically apply the brakes**

Answers

SAMPLE

1. B
2. B
3. C
4. B
5. B
6. A
7. B
8. B
9. B
10. C

SAMPLE

Explanations

SAMPLE

1. What happens if the emergency air line breaks or gets pulled while driving?

- A. The tractor will stall**
- B. The emergency trailer brakes will engage**
- C. The service brakes will engage**
- D. The trailer will detach**

If the emergency air line breaks or gets pulled while driving, the emergency trailer brakes will engage. In a tractor-trailer combination, the emergency air line is responsible for delivering air pressure to the trailer's emergency brakes. This system is designed to activate automatically if there's a loss of air pressure, which could occur due to a line break or disconnection. When this happens, the trailer's brakes will immediately engage to prevent it from rolling away or to slow it down. This safeguard helps maintain control of the vehicle and enhances safety by ensuring that the trailer does not become a hazard on the road. Engaging the emergency brakes is a crucial feature in ensuring that any loss of air in the system does not lead to a more severe situation, such as detachment of the trailer or loss of control of the combined vehicle. This is a vital safety mechanism in preventing accidents and maintaining stability while on the road.

2. What does the "no zone" refer to?

- A. The area around the vehicle where drivers can see clearly**
- B. The blind spots around the vehicle where the driver cannot see**
- C. The zone for parking regulations**
- D. The area required for safe following distance**

The term "no zone" refers specifically to the blind spots around a vehicle where the driver has limited or no visibility. Understanding this concept is crucial for safe driving, particularly when operating combination vehicles or larger trucks. These blind spots can make it challenging for drivers to see vehicles that are adjacent to them, especially to the sides and rear. When you are driving near larger vehicles, it's vital to recognize these no zones to avoid being in an area where the driver of that vehicle cannot see you. Being aware of these blind spots helps enhance safety on the road, as it encourages drivers to maintain a safe distance from larger vehicles and to be more cautious when merging or passing.

3. What action should you take if the trailer begins to fishtail?

- A. Increase speed to pull it back into line**
- B. Slam on the brakes to stop**
- C. Slow down and steer in the direction of the skid**
- D. Turn the steering wheel sharply**

When a trailer begins to fishtail, it indicates that it's experiencing a loss of stability, which can lead to a potentially dangerous situation. The correct action is to slow down and steer in the direction of the skid. This method allows the driver to regain control of both the vehicle and the trailer. Slowing down reduces the speed of the vehicle and trailer, making it easier to regain stability. Steering into the skid allows the driver to realign the front wheels of the tractor with the path of the trailer. By doing so, you can counteract the fishtailing motion, helping to straighten out the vehicle combination. This technique is crucial because it helps maintain control and avoids exacerbating the fishtail situation. Attempting to increase speed in an effort to pull the trailer back into line can lead to further instability and is likely to worsen the fishtailing effect. Similarly, slamming on the brakes can cause the vehicle to skid or lose control entirely, while turning the steering wheel sharply could lead to a jackknife scenario. Thus, the recommended approach of slowing down and steering into the skid effectively addresses the situation by promoting control and stability.

4. What should be done if you experience braking issues while driving a combination vehicle?

- A. Continue driving to the nearest repair shop**
- B. Stop the vehicle immediately and inspect the brakes**
- C. Use engine braking to compensate**
- D. Reduce speed and hope the brakes will improve**

If you experience braking issues while driving a combination vehicle, stopping the vehicle immediately and inspecting the brakes is the safest and most prudent action. This approach prioritizes safety for you, your passengers, and other road users. When braking issues arise, it is crucial to determine the source of the problem before proceeding further. Continuing to drive could result in a complete brake failure, leading to dangerous situations such as collisions or loss of control. By stopping and performing an inspection, you can assess whether any immediate repairs are necessary or whether the vehicle is safe to continue driving. It's also important to be aware that relying on engine braking to compensate for brake issues can be ineffective. Similarly, reducing speed while hoping the brakes will improve does not address the underlying issue and could lead to loss of control, especially if the situation worsens. Seeking a professional assessment of the brakes is the best way to ensure safety on the road.

5. If transporting hazardous materials, what additional requirement must you satisfy?
- A. You need a specialized trailer
 - B. You must have a Hazardous Materials endorsement on your CDL**
 - C. You must notify all passengers
 - D. You need to drive at a lower speed limit

To transport hazardous materials legally, a driver must hold a Hazardous Materials endorsement on their Commercial Driver's License (CDL). This endorsement is crucial as it signifies that the driver has received specialized training in handling hazardous materials, understands the associated risks, and is familiar with the regulations governing the transportation of such materials. It ensures that the driver is prepared to act appropriately in the event of an emergency involving hazardous materials, including knowing how to respond to spills and other incidents. The endorsement also helps regulatory agencies verify that the driver is qualified to carry these materials safely, which is essential for public safety. Without this endorsement, a driver would be violating federal regulations, which could lead to severe penalties for both the driver and the transporting company.

6. What is the potential outcome of not securing the crank handle after raising the iron trailer supports?
- A. The supports may fall off during transit**
 - B. The trailer may become unstable
 - C. The crank handle may become inaccessible
 - D. The vehicle will not start

If the crank handle is not secured after raising the iron trailer supports, the supports could potentially fall off during transit. This is a crucial safety concern because unsecured supports can lead to structural instability. If the supports collapse, it may cause the trailer to detach or become unbalanced while in motion, posing serious risks not only to the vehicle and its cargo but also to other road users. Properly securing the crank handle ensures that the supports remain in place, contributing to the overall safety and stability of the combination vehicle during travel.

7. What is the proper way to back up a combination vehicle?

- A. Back up without checking surroundings**
- B. Always use a spotter when possible and check surroundings frequently**
- C. Back up only when necessary**
- D. Use the rearview camera only**

Using a spotter when backing up a combination vehicle is a critical safety practice. The combination of a tractor and trailer creates significant blind spots, making it challenging for the driver to see obstacles or other vehicles. A spotter can provide guidance and improve visibility, ensuring a safer maneuver. Checking the surroundings frequently is also essential because situational awareness plays a key role in preventing accidents. Even if a spotter is present, the driver should be vigilant about what is happening around them. This dual approach of utilizing a spotter and being aware of the surroundings can help prevent collisions or other dangerous situations while backing up. In contrast to this practice, backing up without checking surroundings can lead to accidents, as the driver would be unaware of any potential hazards. Backing up only when necessary, while a prudent consideration, does not directly address the safest backing techniques. Relying solely on a rearview camera, while a helpful tool, cannot replace the need for a physical spotter and situational awareness. Therefore, the option emphasizing both the use of a spotter and regular checks of the surroundings represents the safest and most conscientious approach to backing up a combination vehicle.

8. What is the consequence of failing to adjust the brakes?

- A. Increased fuel consumption**
- B. Brakes may fail**
- C. Higher vehicle speed**
- D. Improved handling**

Failing to adjust the brakes properly can lead to brake failure, which is a critical safety issue. Brakes require regular maintenance and adjustment to ensure they function effectively. If brakes are too loose or not appropriately aligned, they may not engage properly when needed, which can result in a complete loss of braking ability. This poses a significant risk to the driver, passengers, and others on the road, as it can lead to accidents and collisions due to the inability to stop the vehicle in a timely manner. The need for regular brake adjustments is vital to maintain both vehicle safety and operational reliability.

9. What does it indicate if the fifth wheel locking lever is not locked after the jaws close around the kingpin?

- A. The coupling is secure and ready**
- B. The coupling is not proper and needs adjustment**
- C. The kingpin is damaged**
- D. No action is required**

When the fifth wheel locking lever is not locked after the jaws have closed around the kingpin, this signifies that the coupling has not been secured properly. The locking lever is a critical component in ensuring that the connection between the tractor and trailer is safe and secure. If the lever does not lock, it indicates that the jaws have not fully engaged with the kingpin, which can lead to a dangerous situation while driving. Therefore, adjustment or re-coupling is necessary to ensure that the connection is properly established before operation. The inability of the locking lever to engage could stem from several issues, such as an improperly positioned trailer, dirt or damage in the fifth wheel area, or a malfunction within the fifth wheel mechanism itself. Addressing this condition is crucial to prevent accidents related to trailer detachment during transit.

10. What happens if a driver crosses the air lines when hiking up to an old trailer without spring brakes?

- A. The driver will be unable to start the vehicle**
- B. The trailer brakes will function normally**
- C. The driver can drive away but will lack trailer brakes**
- D. The vehicle will automatically apply the brakes**

When a driver crosses the air lines while hiking up to an old trailer that does not have spring brakes, the result is that the trailer will not have active brakes. The braking system relies on the air from the tractor to maintain proper functionality of the trailer brakes. If the air lines are crossed, it disrupts the supply of air in the proper sequence needed for the brakes to engage. In this scenario, the driver may still be able to drive the vehicle, but the trailer's brakes will not function as intended. This creates a significant safety hazard, as the driver will be operating the vehicle without the ability to effectively stop or control the trailer. It is crucial for drivers to ensure that air lines are correctly connected to prevent such situations and maintain proper braking control over both the tractor and the trailer.